

# **Specification Approval Sheet**

Name:	Tenergy P	Premium C	Size	NiMH	Recharg	geable	Battery	/

Model: 10208

SPEC: 1.2V 5000mAh

Approved By	Checkup	Make

	Signature	Date
0 -1		
Customer Confirmation	Company Name :	
Committation	Stamp:	

436 Kato Terrace, Fremont, CA 94539 U.S.A. Tel: 510.687.0388 Fax: 510.687.0328

www.TenergyBattery.com



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

Specification alteration history				
lo.	Date	Edition	Class*	Main altered item
1	2012-4-27	A/0		New issue

\*: Class A, D and R means added, deleted and revised respectively.



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

# 1.SCOPE

## **BATTERY MODEL**

#### 2.NOMINAL SPECIFICATION

2.1.Nominal voltage 2.2.Nominal capacity*	1.2V 5000mAh
2.3.Minimum capacity*	5000mAh
2.4.Charging	
Standard charging	500mA for 16 hours
Quick charging	1000mA for 7 hours
Rapid charging	2500mA for 2.4hours, $-\Delta V=5mV$
2.5.End voltage of discharge	1.0V
2.6.Temperature (recommended)	
Standard charge	0~40°C
Quick charge	10~40°C
Rapid charge	10~30°C
Discharge:	-10~50°C
Storage	
Less than 30 days	-20~50°C
Less than 90 days	-20~40°C
Less than 1 year	-20~30°C
2.7.Relative humidity	45~85%
2.8.Weight	Approx. 86g
2.9.Dimensions	shown in the page 10

Note \*:Discharge capacity when the battery unit is discharged at 1000mA after being standard charged. Five cycles are permitted for this test .The test shall be terminated at the end of the first cycle which meets the requirement.

\*\*: Unless otherwise stated in these specifications, the battery unit should be discharged to 1.0V end voltage with 1000mA before charging.

#### 3. APPEARANCE

There shall be no practical damage such as conspicuous liquid electrolyte leakage, flow and dirt under conditions of storage or operation as specified herein.



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

# 4.ELECTRICAL CHARACTERISTICS

**Testing conditions** 

The battery shall be evaluated within 1 month from the arrival date.

Unless otherwise stated in these specifications, the following test shall be carried out in an ambient temperature of 20±5°C, relative humidity of 65±20%.

#### Characteristics

Test Items	Test Conditions	Requirement	Remark
4.1 Open-circuit Voltage (OCV)	Voltage between the battery terminals shall be measured within 14 days after standard charge	≥1.25V	
4.2 Capacity	After standard charge, rest for 1 hour before discharge to 1.0V at 1000mA current	Discharge Capacity: ≥5000 mAh	Up to 5 cycles are allowed
4.3 High-rate discharge(0.5C)	After standard charge, rest for 1 hour before discharge to 1.0V at 2500mA current	≥110 minutes	Up to 5 cycles are allowed
4.4 High-rate discharge (1C)	After standard charge, rest for 1 hour before discharge to 0.9V at 5000mA current	≥52 minutes	Up to 5 cycles are allowed
4.5 Low temperature discharge	Within 1 hour after standard charged at 20°C, discharged at a current of 1000mA to 1.0V at 0°C	≥240 minutes	
4.6 High temperature discharge	Within 1 hour after standard charged at 40°C, discharged at a current of 1000mA to 1.0V at 20°C	≥240 minutes	
4.7 Internal impedance (Ri)	Upon fully charge (1KHz)	Max.8mΩ	



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

Test Items	Test Conditions	Requirements	Remark
4.8 IEC cycle life	IEC61951-2(2011)7.5.1.2 See Remark 1	≥500 Cycles	
4.9 Charge retention  Standard charged ,stored for 28 days at 20±2°C , discharged at a current of 1000mA to 1.0V		≥210 Minutes	
4.10 Over-charge	Within 1 hour after being charged at a current of 500mA for 48 hours, the battery unit shall be discharged at 20°C, at a current of 1000mA to 1.0V end voltage	≥300 Minutes	
4.11 Continuous low-rate charging	After standard charged battery unit is charged at 150mA~250mA for 28 days	No fire , nor explosion	
4.12 Forced discharge	The discharged battery unit is subjected to a reverse charge at 5000mA for 90 minutes	No fire , nor explosion	
4.13 Vibration IEC62133 ( 2002 ) 4.2.2 See Remark 2		No leakage, nor fire , nor explosion	

#### \*REMARK:

1. Cycle life: IEC61951-2(2011) 7.5.1.2

	\ /		<del>-</del>
Cycles	Charge	rest	Discharge
1	0.1C×16hrs	0	0.25C×2hrs 20mins
2~48	0.25C×3hrs 10mins	0	0.25C×2hrs 20mins
49	0.25C×3hrs 10mins	0	0.25C to 1.0V/cell
50	0.1C×16hrs	1~4hrs	0.20C to 1.0V/cell
Cycle 1 to 50 shall be repeated until the discharge duration on any 50 <sup>th</sup> cycle become less than 3hrs			



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

www.TenergyBattery.com email: sales@tenergybattery.com

2. Vibration: IEC62133 ( 2002 ) 4.2.2

Frequency	10~55Hz
Amplitude	0.76mm
Rate of frequency variety	1 Hz/minute
Duration	90 minutes /axis (axis: X、Y、Z) 270 minutes in all

# 5. ENVIRONMENTAL PROTECTION REQUIREMENT

- 5.1 The requirement on Hazardous Substances in the materials should comply with Tenergy's criterion.
- 5.2 The requirement on Hazardous Substances in the Products should comply with 2006/66/EC and Tenergy's criterion.

#### 6. TRANSPORT

To ensure battery safety during delivery, SOC( state of charge) must be below 30%, inside temperature of container could not be over 35°C. Product holder should be responsible for any possible loss during delivery if above conditions cannot be met completely.

Inside temperature of container must be below 20°C if any client requires SOC(state of charge)above 30%, the distance between battery master cartons should be not less than 10cm in container, and coercive air cross ventilation system is required in container to ensure even temperature for each master carton. Product holder should be responsible for any possibly accidental loss if above conditions cannot be met completely.

#### 7.PRECAUTION

Please keep in mind the following points when designing and manufacturing equipment. Please insert in your instruction manual. To prevent equipment malfunctions from affecting the batteries, be sure to use protection devices for electrical circuits and batteries.

#### **▲Danger!**

- Failure to carefully observe the following procedures and precautions can result in leakage of battery fluid (electrolyte), heat generation, explosion, fire and serious personal injury!
- · Never dispose of TENERGY batteries in a fire or heat them.

Do not connect the (+) positive and (-) negative terminals of TENERGY batteries together with electrically conductive materials, including lead wires. Do not transport or store TENERGY batteries with their uncovered terminals or connected with a metal necklace or other electrically conductive



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

material. When carrying or storing batteries, use a special case.

- Only charge TENERGY batteries using those specific chargers that satisfy TENERGY'S specifications. Only charge batteries under the conditions specified by TENERGY.
- Never disassemble TENERGY batteries. Doing so may cause an internal or external short circuit or result in exposed material of battery reacting chemically with the air. It may also cause heat generation, explosion and fire. Also, this is dangerous as it may cause splashing of alkaline fluid.
- · Never solder lead wires directly on to TENERGY batteries.
- The (+) positive and (-) negative terminals of TENERGY batteries are predetermined. Do not force the terminals to connect to a charger or equipment. If the terminals cannot be easily connected to the charger or the equipment, check if the (+) and (-) terminals are incorrectly positioned.
- The gas release vent which release internal gas is located in the (+) positive terminal of the TENERGY battery. For this reason, never deform this section or cover or obstruct its gas release structure.
- Do not directly connect TENERGY batteries to a direct power source or the cigarette lighter socket in a car.
- Do not use TENERGY batteries in any equipment other than those specified by TENERGY.
- TENERGY batteries contain a strong colorless alkaline solution (electrolyte). The alkaline solution is extremely corrosive and will cause skin damage. If any fluid from a TENERGY battery comes in contact with user's eyes, they should immediately flush their eyes and wash them thoroughly with clean water from the tap or another source and consult a doctor urgently. The strong alkaline solution can damage eyes and lead to permanent loss of eyesight.
- When TENERGY batteries are to be incorporated in equipment or housed within a case, avoid airtight structures, as this may lead to the equipment or the case being damaged or may be harmful to users.

#### **∆Warning!**

• Do not apply water, seawater or other oxidizing reagents to TENERGY batteries, as this can cause rust and heat generation. If a battery becomes rusted, the gas release vent may no longer operate, and can result in explosion.



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

- Do not over-charge TENERGY batteries by exceeding the predetermined charging period specified by the battery charger's instructions or indicator. If TENERGY batteries are not fully charged after the battery charger's predetermined charging period has clasped, stop the charging process. Prolonged charging may cause leakage of battery fluid, heat generation, and explosion. Be sure to handle recharged batteries carefully as they may be not.
- TENERGY batteries contain a strong colorless alkaline solution (electrolyte). If the skin or clothing comes in contact with fluid from a TENERGY battery; thoroughly wash the area immediately with clean water from the tap or another source. Battery fluid can irritate the skin.
- Do not connect more than 21 TENERGY batteries in series, as this may cause electrical shocks, leakage of battery fluid and heat generation.
- Do not remove the outer tube from a battery or damage it. Doing so will expose the battery to the risk of a short circuit, and may cause leakage of battery fluid, heat generation, explosion and fire.
- If TENERGY batteries leak fluid, change color, change shape, or change in any other way, do not use them, otherwise they may cause heat generation, explosion and fire.
- Keep TENERGY batteries and the equipment using them out of the reach of babies and small children, in order to avoid accidental swallowing of the batteries. In the event the batteries are swallowed, consult a doctor immediately.
- When the operating time of a TENERGY battery becomes much shorter than its initial operating time even after recharged, it should be replaced to a new battery as its battery life has ended.

#### **∆CAUTION!**

- Do not strike or drop TENERGY batteries.
- Store TENERGY batteries out of the reach of babies and small children. When charging or using a
  battery, do not let babies or small children remove the battery from the charger or the equipment
  being used.
- Be sure to charge TENERGY batteries within a temperature range of 0 to 40 deg C (degrees Celsius).
- Be sure to use the recommended charging method for TENERGY batteries read the battery charger's instruction manual carefully.
- Do not use or store battery at high temperature, such as in strong direct sunlight, in cars during hot



436 Kato Terrace Fremont, CA 94539

Tel: 510.687.0388 Fax: 510.687.0328

<u>www.TenergyBattery.com</u> email: sales@tenergybattery.com

weather, or directly in front of a heater. This may cause leakage of battery fluid. It could also impair performance and shorten operating life of TENERGY batteries.

- Be sure to turn off the equipment after use of TENERGY batteries, otherwise may result in leakage of battery fluid.
- ◆ After removed from equipment, store TENERGY batteries in a dry place and within the recommended storage temperature range. This will help preserve the batteries' performance and durability and minimize the possibility of leakage of battery fluid or corrosion. (TENERGY recommends the storage temperature range from -20 to +30deg.(for longer service life).
- Storage batteries should be charged one time every four months under the storage temperature of 30°C and below, every three months under 40°C and below, and every one month under 50°C and below.
- After long term storage, there is a possibility that the battery could not be fully charged. In order to fully charge it, please charge and discharge battery for a few times.
- Do not use old and new batteries mixed together, or batteries at different charge levels. Do not use the TENERGY battery mixed with a dry cell or other batteries of different capacity, type, or brand name. This may cause leakage of battery fluid and heat generation.
- If the TENERGY battery terminals become dirty, clean up them with a soft dry cloth prior to use. Dirt on the terminals can result in poor contact with the equipment, loss of power, or inability to charge.

#### 8. WARRANTY

TENERGY will be responsible for replacing the battery against any defects or poor workmanship for six months from the date of shipping.

Any other problems caused by malfunction of the equipment or misuse of the battery are not under this warranty.

**Notice:** To assure safety, please consult to the TENERGY technical staff for your applications including electrical specifications, mechanical designs, protective devices and any special specification. TENERGY reserve the right to alter or amend the design, model and specification without prior notice.