## Battery Failsafe Devices 805-683-9684 PST

www.so-bfd.com

## LCD-HV Low Battery Alarm, 12 to 48 Volt Monitoring



## Set Points for LCD-HV Low Battery Alarm

+12 Volt	+24 Volt	+36 Volt	+48 Volt
12.40	24.80	37.20	49.60
12.20	24.40	36.80	48.80
12.00	24.00	36.00	48.00
11.80	23.60	35.40	47.20
11.60	23.20	34.80	46.40
11.40	22.80	34.20	45.60
11.20	22.40	33.60	44.80
11.00	22.00	33.00	44.00
10.80	21.60	32.40	43.20

Micro processor controlled Low Battery Alarm for all battery systems. Prevent low or dead batteries by installing the Low Battery Alarm which has both LED and audible alarm. This device will monitor your battery voltage and warn you of unsafe levels. The Low Battery Alarm is completely user adjustable with 9 low voltage settings to support your battery voltage needs.

Ideal battery protection for RV's, autos, boats, generators or any device a battery may be critical to operation. Design to meet all the needs of all battery systems.

## **Features:**

- Auto voltage sensing from 12 up to 48 volts
- Current draw of only +2.0 milliamps
- Easy to read LCD voltage read out
- Senses voltage when connected to battery source
- Easy adjustable 22 low voltage alarm set points
- Loud audible alarm with LED visual warning
- Prevents battery failure and battery cell damage
- 6 foot DC power cord
- Optional Relay switching control available
- Optional panel mount External 105dB Buzzer
- Optional LED Spot Lamp for distant viewing
- Mounting tabs for best viewing location
- 1 Year Warranty

Battery Failsafe Devices 805-683-9684 PST

www.so-bfd.com